



APPLICATION NOTE - SR002

Surface Preparation

Surface preparation is important to successful application and performance of Silent Running.

All surfaces should be clean, dry, dust and oil free.

For shiny surfaces such as fiberglass gel coat, metals that have been coated with a protective coating, or even wood with a finish coat on them, abrade the surface in a well defined cross hatch pattern for best adhesion. Vacuum or tack rag to ensure all dust is removed.

If there is any rust or corrosion, chip, grind, scrape or sand to get all loose and flaking material off.

The better the surface prep, the better Silent Running will adhere and perform.

If there are any question concerning the application of Silent Running, please contact us at the numbers below.

Current Inc.
30 Tyler Street
PO Box 120183
East Haven, CT 06512

Current Composites Coatings
Phone: 203-469-1337
Toll free: 877-436-6542
Fax: 203-467-8435