



## Wet Film Gauge Directions

1. Select one of the four sides of the gauge according to the approximate wet film thickness.  
One coat applied by brush or roller should be 8-12 mils thick. One coat applied by sprayer can be 15-20 mils thick.

2. Hold the gauge perpendicular to surface and press it into the wet coating until the gauge rests squarely on the base (substrate).

**DO NOT DRAG OR TWIST THE GAUGE**

3. Withdraw the gauge and note the **deepest** tooth which has Silent Running on it and the next higher tooth that does not. The true wet film thickness lies between these two readings.
4. After use clean immediately in water.



Visit Our Web Site At:  
[WWW.SILENTRUNNING.US](http://WWW.SILENTRUNNING.US)  
E-Mail: [info@silentrunning.com](mailto:info@silentrunning.com)